## Project\_matrix

## May 11, 2022

```
import matplotlib.pyplot as plt
import os
import pandas as pd
import requests
import sys
import xarray as xr
import scipy
from scipy import interpolate
from matplotlib.dates import DateFormatter
from time import sleep
import numpy as np
```

```
[]: begindate = '20190917' # data is avail. beginning 20180917 enddate = '20190922'
```

Select Input Parameters

```
[]: #Generating inflow for channel 1
     comid_all = ['1475119','1475125','1475121','1475141']
     inflow1 = pd.DataFrame()
     totalinflow = pd.DataFrame()
     outflow1 = pd.DataFrame()
     totaloutflow = pd.DataFrame()
     len(comid_all)
     for i in range(len(comid_all)):
         comid = comid_all[i]
         input1 = pd.read_csv('D:/Sujana/Project/ce397/csv_project/'+str(comid)+'.
     ⇔csv')
         inflow1['Time'] = input1['Time']
         inflow1[i] = input1['Total_inflow']
         outflow1[i] = input1['Discharge_NWM(m3/s)']
     inflow1['Total_inflow'] = inflow1[0]+inflow1[1]+inflow1[2]+inflow1[3]
     outflow1['Outflow1'] = outflow1[3]
     headerlist = ['Time','1475119','1475125','1475121','1475141','Total_inflow']
     totalinflow['Time'] = inflow1['Time']
```

```
totalinflow['Inflow_1'] = inflow1['Total_inflow']
totaloutflow['Time'] = inflow1['Time']
totaloutflow['Outflow1'] = outflow1['Outflow1']
inflow1.to_csv(r'D:/Sujana/Project/ce397/csv_project/Inflow1.csv',

header=headerlist)
```

```
[]: #Generating inflow for channel 2
     comid_all2 = ['1475151','1475149']
     inflow2 = pd.DataFrame()
     outflow2 = pd.DataFrame()
     len(comid all2)
     for i in range(len(comid_all2)):
         comid = comid_all2[i]
         input2 = pd.read_csv('D:/Sujana/Project/ce397/csv_project/'+str(comid)+'.
     ⇔csv')
         inflow2['Time'] = input1['Time']
         inflow2[i] = input2['Total inflow']
         outflow2[i] = input1['Discharge_NWM(m3/s)']
     inflow2['Total_inflow'] = inflow2[0]+inflow2[1]
     outflow2['Outflow2'] = outflow2[0]+outflow2[1]
     headerlist = ['Time','1475151','147149','Total_inflow']
     totalinflow['Inflow_2'] = inflow2['Total_inflow']
     totaloutflow['Outflow2'] = outflow2['Outflow2']
     inflow2.to_csv(r'D:/Sujana/Project/ce397/csv_project/Inflow2.csv', __
      →header=headerlist)
```

Creating 15 min time series and interpolating data

```
[]: def interpolation(x, y, xnew):
    interp_fun = interpolate.interp1d(x, y, fill_value='extrapolate')
    y_interp = interp_fun(xnew)
    return(y_interp)
```

```
[]: new_flow = pd.DataFrame()
     series = pd.date_range(start='2019-09-17', end='2019-09-22', freq='15 min')
     new_flow['Time'] = series
     series = [x.timestamp() for x in series] #Converts time to seconds for⊔
     \rightarrow interpolation
     x = pd.to_datetime(totalinflow['Time'])
     x = [var.timestamp() for var in x]
     xnew = series
     I1 = interpolation(x,totalinflow['Inflow_1'],xnew)
     I2 = interpolation(x,totalinflow['Inflow_2'],xnew)
     I3 = interpolation(x,totalinflow['Inflow_3'],xnew)
     01 = interpolation(x,totaloutflow['Outflow1'],xnew)
     02 = interpolation(x,totaloutflow['Outflow2'],xnew)
     03 = interpolation(x,totaloutflow['Outflow3'],xnew)
     new flow['Inflow1 15min'] = I1
     new_flow['Inflow2_15min'] = I2
    new_flow['Inflow3_15min'] = I3
    new_flow['Outflow1_15min'] = 01
    new_flow['Outflow2_15min'] = 02
     new_flow['Outflow3_15min'] = 03
     new_flow.to_csv(r'D:/Sujana/Project/ce397/time_interval_15min/15min_flow.csv')
X1 = 0 \#-7.2
     delta t = 15*60
     alpha1 = (delta_t-2*K1*X1)/(2*K1*(1-X1)+delta_t)
     beta1 = (delta t+2*K1*X1)/(2*K1*(1-X1)+delta t)
     xi1 = (2*K1*(1-X1)-delta_t)/(2*K1*(1-X1)+delta_t)
     K2 = 7.697 \# 7.3317
     X2 = 0
     delta_t = 15*60
     alpha2 = (delta_t-2*K2*X2)/(2*K2*(1-X2)+delta_t)
     beta2 = (delta_t+2*K1*X1)/(2*K2*(1-X2)+delta_t)
     xi2 = (2*K2*(1-X1)-delta_t)/(2*K2*(1-X2)+delta_t)
     K3 = 7.722
     X3 = 0
     delta_t = 15*60
     alpha3 = (delta_t-2*K2*X2)/(2*K2*(1-X2)+delta_t)
     beta3 = (delta_t+2*K2*X2)/(2*K2*(1-X2)+delta_t)
     xi3 = (2*K2*(1-X2)-delta t)/(2*K2*(1-X2)+delta t)
```

```
[]: #Define the matrices
     import numpy as np
     import pandas as pd
     B_I = np.array([0,0,0,0,0,0,beta1,beta2,0]).reshape(3,3)
     X_I = \text{np.array}([0,0,0,0,0,0,xi1,xi2,0]).\text{reshape}(3,3)
     B_0 = np.array([beta1,0,0,0,beta2,0,alpha3*beta1,alpha3*beta2,beta3]).
     \rightarrowreshape(3,3)
     X_0 = \text{np.array}([xi1,0,0,0,xi2,0,alpha3*xi1,alpha3*xi2,xi3]).reshape(3,3)
     P_I = np.array([1,0,0,0,1,0,alpha1,alpha2,1]).reshape(3,3)
     P_O = np.array([alpha1,0,0,0,alpha2,0,alpha3*alpha1,alpha3*alpha2,alpha3]).
      \rightarrowreshape(3,3)
[]: df = pd.read_csv('time_interval_15min/15min_flow.csv')
     mat_6x6 = np.block([[B_I,X_I],[B_0,X_0]]) # Creating 6x6 Matrix
     mat 6x3 = np.block([[P I],[P 0]]) # Creating 6 * 3 matrix
     I_intial=np.array([0,0,0]).reshape(3,1) # Intializing I matrix
     0 intial=np.array([0,0,0]).reshape(3,1) # Initializing O matrix
     IO_mat_6x1 = np.block([[I_intial],[O_intial]]) # Creating a block matrix
[]: P1 = np.array(df['Inflow1_15min'])
     P2 = np.array(df['Inflow2_15min'])
     P3 = np.array(df['Inflow3_15min'])
     time = df['Time']
     result = IO mat 6x1.reshape(1,6) # Initialing result with initial value for
     \rightarrow Input and output
     for idx in range(len(P1)): # running till the length of P1 i.e. the number of
      \rightarrow time steps
         P_t = np.array([[P1[idx]], [P2[idx]], [P3[idx]]]) # extracting value of
      → each arrary for each time step
         val = mat_6x6@result[-1,:].reshape(6,1)+mat_6x3@P_t # selecting the last_
      \rightarrowvalue of result and reshaping it to 6x1
         val = val.reshape(1,6)
         result = np.concatenate((result,val),axis=0) # each row result for each_
      \hookrightarrow time step
     # np.savetxt('time_interval_15min/result_outflow.csv', result, delimiter=",")
```

Save the Modeled Outflows as CSV

```
[ ]: new_result = pd.DataFrame()
     new_result['Time'] = df['Time']
     new_result['Model_I1'] = result[1:,0]
     new_result['Model_I2'] = result[1:,1]
     new_result['Model_I3'] = result[1:,2]
     new_result['Model_01'] = result[1:,3]
    new_result['Model_02'] = result[1:,4]
     new_result['Model_03'] = result[1:,5]
     new_result.to_csv('D:/Sujana/Project/ce397/time_interval_15min/15min_modelflow.
      ⇔csv¹)
[]: from sklearn.metrics import mean_squared_error
     from math import sqrt
     rms1 = np.sqrt(mean_squared_error(new_result['Model_01'], df['Outflow1_15min']))
     rms2 = np.sqrt(mean_squared_error(new_result['Model_02'], df['Outflow2_15min']))
     rms3 = np.sqrt(mean_squared_error(new_result['Model_03'], df['Outflow3_15min']))
[]: # plot the discharge time series
     import matplotlib.pyplot as plt
     from matplotlib.dates import DateFormatter
     time= pd.to_datetime(time)
     # Outflow1
     plt.figure(facecolor='white')
     plt.rc('font', size=18)
     fig, ax = plt.subplots(figsize=(10, 6))
     ax.plot(time, df['Outflow1_15min'], label='NWM')
     ax.plot(time, result[1:,3], label='Model')
     ax.set(xlabel='Date',
            ylabel='Discharge [cms]',
            title='Model vs NWM outflow1')
     date form = DateFormatter("%b %d")
     ax.xaxis.set_major_formatter(date_form)
     ax.legend()
     ax.grid(True)
     # plt.show()
     plt.savefig('time_interval_15min/Model vs NWM outflow1.jpg')
     # Outflow2
     plt.figure(facecolor='white')
     plt.rc('font', size=18)
     fig, ax = plt.subplots(figsize=(10, 6))
     ax.plot(time, df['Outflow2_15min'], label='NWM')
     ax.plot(time, result[1:,4], label='Model')
     ax.set(xlabel='Date',
            ylabel='Discharge [cms]',
```

```
title='Model vs NWM outflow2')
     date_form = DateFormatter("%b %d")
     ax.xaxis.set_major_formatter(date_form)
     ax.legend()
     ax.grid(True)
     # plt.show()
     plt.savefig('time_interval_15min/Model vs NWM outflow2.jpg')
     # Outflow2
     plt.figure(facecolor='white')
     plt.rc('font', size=18)
     fig, ax = plt.subplots(figsize=(10, 6))
     ax.plot(time, df['Outflow3_15min'], label='NWM')
     ax.plot(time, result[1:,5], label='Model')
     ax.set(xlabel='Date',
           ylabel='Discharge [cms]',
           title='Model vs NWM outflow3')
     date_form = DateFormatter("%b %d")
     ax.xaxis.set_major_formatter(date_form)
     ax.legend()
     ax.grid(True)
     # plt.show()
     plt.savefig('time_interval_15min/Model vs NWM outflow3.jpg')
[]: #Import file for Rating Curve
     import pickle
     rating_curves = pickle.load( open( "D:/Sujana/Project/rating_curves_dict.p", __
     []: # Get relevant rating curve for specific stream
     rc120402 = rating_curves['120402']
[]: # Get the rating curve for the specific stream in this huc6.
     rating_curve_gage = rc120402[rc120402['CatchId']==1475141]
[]: #View rating curve data
     rating_curve_gage
[]: def interpolate_discharge(stage_difference, rating_curves):
         interpolates the discharge for the DD6 gage for each comid
        Parameters:
         nwm discharge : float or list
             the nwm discharge value that we're looking to interpolate
             could be a list of values
```

```
catch_id : string
    a list of discharge values
stage_list : list
    the corresponding list of stage values

Returns
-----
interp_val : float or list
    interpolated values for the nwm_discharge
"""
interpolated_discharge = list()
for idx, stage in stage_difference['dd6_stage_m'].iteritems():
    discharge_list = list(rating_curve_gage['Discharge (m3s-1)'])
    stage_list = list(rating_curve_gage['Stage'])
    y_interp = interp1d(stage_list, discharge_list, u

fill_value='extrapolate')
    interpolated_discharge.append(float(y_interp(stage)))
    return interpolated_discharge
```

```
[]: # Interpolation to convert DD6 stage to discharge
     from scipy.interpolate import interp1d
     import matplotlib.dates as mdates
     # Get the interpolated discharge from rating curves
     gauge_name = 'JZFT2'
     stage_difference = pd.read_csv('DD6_JZFT2.csv')
     stage_difference['dd6_stage_m'] = stage_difference['value'] / 3.28084
     stage_difference['interp_dd6_discharge'] = __
     →interpolate_discharge(stage_difference, rating_curves)
     #Remove bias in DD6 data
     stage_difference['interp_dd6_discharge'] = __
     ⇔stage_difference['interp_dd6_discharge']
     stage_difference['timestamp']=pd.to_datetime(stage_difference['timestamp'])
       # drop meaningless columns
     # discharge_difference = discharge_difference.drop(columns=['Unnamed: 0'])
         # drop duplicate rows
     # discharge_difference = discharge_difference.drop_duplicates()
         # save as csv
```

```
stage_difference.to_csv(r'D:/Sujana/Project/ce397/DD6_stage_with_discharge.
\hookrightarrowcsv', index=False)
# nwm_discharge = pd.read_csv('Total_Discharge_nwm.csv')
nwm discharge = pd.read csv('D:/Sujana/Project/ce397/time interval 15min/
→15min flow.csv')
nwm_discharge['Time'] = pd.to_datetime(nwm_discharge['Time'])
  # Plotting discharge-time series
plt.figure(facecolor='white')
plt.rc('font', size=14)
fig, ax = plt.subplots(figsize=(10, 6))
  # time = discharge_difference['Time']
  # print (time)
ax.plot(stage_difference['timestamp'],__
→stage_difference['interp_dd6_discharge'],color='k', label='DD6 Discharge')
ax.plot(nwm_discharge['Time'], nwm_discharge['Outflow1_15min'],color='tab:
⇔blue', label='NWM_Discharge')
ax.plot(nwm_discharge['Time'], result[1:,3],color='r', label='Model_Discharge')
ax.set(xlabel='Date',
      ylabel='Discharge [m3/s]',
      title=f'COMID {comid} {gauge_name} from ' \
      f'{pd.to_datetime(begindate).strftime("%b %d %Y")} to ' \
      f'{pd.to_datetime(enddate).strftime("%b %d %Y")} for analysis/
 →assimilation')
date_form = DateFormatter("%b %d")
ax.xaxis.set_major_formatter(date_form)
ax.legend()
ax.grid(True)
plt.savefig('D:/Sujana/Project/ce397/time_interval_15min/
 →Discharge_graph_analysis_an.jpg')
```

Finding the equivalent DD6 data for the Model data

```
model_data['Time'] = pd.to_datetime(model_data['Time'], utc=True)
   dd6_data['timestamp']=pd.to_datetime(dd6_data['timestamp'],utc=True)
   dd6_data = dd6_data.set_index('timestamp')
   model_data = model_data.set_index('Time')
   \# getting the list of indexes in num data that is closet to each dd6\_data
   indx_list = [get_location(dd6_data,x) for x in model_data.index]
# assigning the filtered indexes to the num discharge
   nwm_discharge_filtered = dd6_data.iloc[indx_list]
   nwm discharge filtered['Date']=model data.index
   nwm_discharge_filtered = nwm_discharge_filtered.reset_index()
   sensor = pd.DataFrame()
   sensor['Time'] = nwm_discharge_filtered['Date']
   sensor['DD6_stage(m)'] = nwm_discharge_filtered['dd6_stage_m']
   sensor['DD6_discharge'] = __
→nwm_discharge_filtered['interp_dd6_discharge']#-133.3
   sensor.to_csv('D:/Sujana/Project/ce397/time_interval_15min/DD6_sensor_15min.
 ⇔csv')
```

```
[]: #Load the sensor data and model data
     sensor = pd.read_csv('D:/Sujana/Project/ce397/time_interval_15min/
     →DD6_sensor_15min.csv')
     Y = np.array(sensor['DD6 discharge'])
     X = pd.read csv('D:/Sujana/Project/ce397/time interval 15min/15min modelflow.
     ⇔csv')
     I1 = np.array(X['Model_I1'])
     I2 = np.array(X['Model_I2'])
     I3 = np.array(X['Model_I3'])
     01 = np.array(X['Model_01'])
     02 = np.array(X['Model 02'])
     03 = np.array(X['Model_03'])
     C = np.array([1/4,0,0,3/4,0,0]).reshape(1,6)
     #Define noise parameters
     sigma_v = 0.05
                          # Measurement noise std. dev
                         # Process noise std. dev
     sigma_w = 0.2
                          # Add measurement noise by setting to 1
     add_v = 0
     add_w = 0
                            # Add process noise by setting to 1
     # Y += add_v * sigma_v * np.random.randn(*Y.shape) # Add noise to_
     \rightarrow observations
```

```
[]: A = np.block([[B_I,X_I],[B_0,X_0]])
B = np.block([[P_I],[P_0]])
V = sigma_v**2 * np.eye(len(C)) # Measurement noise covariance
```

```
W = sigma_w**2 * np.eye(len(A)) # Process noise covariance
S = 1e-2 * np.eye(len(A)) # Initial estimate of error covariance
x_hat = np.zeros(6).reshape(1,6) # Estimate of initial state
\# X_hat = [x_hat]
for k in range(len(I1)):
   y = Y[k]
    u = np.array([[P1[k]], [P2[k]], [P3[k]]])
    \# u += add_w * sigma_w * np.random.randn(B.shape)
    S = mat_6x6 @ (S - S @ C.T @ np.linalg.inv(C @ S @ C.T + V) @ C @ S) @_L
\rightarrowmat_6x6.T + W
    \# L = mat_6x6 @ S @ C.T @ np.linalq.inv(C @ S @ C.T + V)
    L = S @ C.T @ np.linalg.inv(C @ S @ C.T + V)
    y_hat = C @ (mat_6x6 @ x_hat[-1,:].reshape(6,1) + mat_6x3 @ u)
    x = mat_{6x6} @ x_{hat}[-1,:].reshape(6,1) + mat_{6x3} @ u + L @ (y - y_{hat})
    x = x.reshape(1,6)
    x_hat = np.concatenate((x_hat,x),axis=0)
X_hat = x_hat
```

```
[]: # plot the discharge time series
     import matplotlib.pyplot as plt
     from matplotlib.dates import DateFormatter
     time= pd.to_datetime(time)
     # Outflow1
     plt.figure(facecolor='white')
     plt.rc('font', size=18)
     fig, ax = plt.subplots(figsize=(10, 6))
     ax.plot(time, 01, label='Model')
     ax.plot(time, Y, label='Sensor')
     ax.plot(time, X_hat[1:,3], label='Filtered')
     ax.set(xlabel='Date',
            ylabel='Discharge [cms]',
            title='Outflow at Channel 1')
     date_form = DateFormatter("%b %d")
     ax.xaxis.set_major_formatter(date_form)
     ax.legend()
     ax.grid(True)
     # plt.show()
     plt.savefig('time_interval_15min/outflow1_an.jpg')
     #Outflow 2
     plt.figure(facecolor='white')
     plt.rc('font', size=18)
     fig, ax = plt.subplots(figsize=(10, 6))
```

```
ax.plot(time, 02, label='Model')
ax.plot(time, X_hat[1:,4], label='Filtered')
# ax.plot(time, Y, label='Sensor')
ax.set(xlabel='Date',
      ylabel='Discharge [cms]',
       title='Outflow at channel 2')
date_form = DateFormatter("%b %d")
ax.xaxis.set_major_formatter(date_form)
ax.legend()
ax.grid(True)
# plt.show()
plt.savefig('time_interval_15min/outflow2_an.jpg')
#Outflow 3
plt.figure(facecolor='white')
plt.rc('font', size=18)
fig, ax = plt.subplots(figsize=(10, 6))
ax.plot(time, 03, label='Model')
ax.plot(time, X_hat[1:,5], label='Filtered')
# ax.plot(time, Y, label='Sensor')
ax.set(xlabel='Date',
       ylabel='Discharge [cms]',
       title='Outflow at Channel 3')
date form = DateFormatter("%b %d")
ax.xaxis.set_major_formatter(date_form)
ax.legend()
ax.grid(True)
# plt.show()
plt.savefig('time_interval_15min/outflow3_an.jpg')
```